







Position	Code	description
	6932102800	BRACKET
	5332224100	MOTOR BELT
	5332164700	RUNNER FRAME
	5013252911	WIRING FOR FLOWMETER (L630)
	5313211301	BLACK REAR PANEL CAP
	5313215891	SCUFF-PROOF RUBBER PAD
	5313231911	MOTOR COVER
	5313231921	MOTOR SUPPORT
	6113210111	FIXING BRACKET (TCO)
	6113210121	SENSOR BRACKET
	6913210021	SOLENOID VALVE SUPPORT (2V)
	6913210031	SOLENOID VALVE SUPPORT (3V)
	6913210011	POD SUPPORT
	5032110800	POWER SUPPLY CORD WITH PLUG (SCHUKO)
	5313242831	TANK PRESENCE CAM
	5313268371	COVER
	5313219181	GRINDER BELLOW GASKET
	5313228141	CONTROL BOARD BOX
	5313239751	GRINDER PANEL
	5013257331	CABLING WITH FUSE (1.25 A)
	IT1000	PORTABLE DIGITAL THERMOMETER (-50°C +150°C)
	SER0354	GREASE TUBE (5GR VERKOFOOD)
001	5313212161	REAR PANEL
002	5132112500	SWITCH
003	5513217131	LEFT SIDE
004	5313229871	WATER INTAKE TUBE
005	5313228331	MIXING MAGNETIC PADDLE
006	7313246061	CARAFE ASSEMBLY
007	5313226131	SWITCH HOLDER
010	5313228721	DREGS TRAY
014	5513217091	GROUND COFFEE COVER
015	5332226300	MEASURING SPOON
016	5513217081	COFFEE BEANS COVER
017	535714	STOPPER
018	5313210961	GRINDING ADJUSTMENT KNOB
019	5513217101	COVER WITH CUP WARMER

020	5513215971	COFFEE BEANS TANK WITH RUBBER PADS
021	5332213200	RUBBER PAD
022	5513217061	DISPLAY BOARD
023	7313225201	CONTROL PANEL FRONT PIECE
024	5513218601	WATER TANK FRONT PIECE
025	5513217121	RIGHT SIDE
026	6132104900	PIN
027	7313223761	DOOR ASSEMBLY
028	7013211211	CUP HOLDER
029	5313228301	CUP HOLDER TRAY
030	5513217141	MOTOR HOUSING BASE WITH RUBBER PADS
031	5313229731	RUBBER FOOT PAD
032	5313229861	FROTHER NICHE
033	7313254491	WATER TANK
034	5313234161	WATER TANK COVER
035	5313213291	HOSE COUPLING COVER
036	5313235921	TANK GASKET
037	5313214981	WATER TANK FILTER
038	6113210251	SPRING
043	7313232361	HOT WATER SPOUT
044	5332177500	O-RING
046	5313231221	STEAM NOZZLE
047	5513270219	FROTHER
048	5313228651	FLOAT
049	5313229871	WATER INTAKE TUBE
51	5513294541	MILK JUG DLSC008
055	7313230461	GRINDER ASSEMBLY (3D-DL 230V)
056	5313227651	FINGER STOP COVER
060	6132104700	SPRING
061	5332142200	SUPPORT
062	5332238300	DRAIN HOSE (90°)
065	5213212381	MOTOR BOARD (ECM 230V)
066	7313217261	MOTOR WITH PULLEY (ECM 230V)
067	5132110500	MICROSWITCH (250V 85°)
068	5513227951	TRANSMISSION ASSEMBLY (CHIAPHUA 230V)
069	5313243071	TOOTHED BELT
070	5213213971	HALL SENSOR (L620)
072	5213215571	POWER BOARD (SW1.1 230V)

073	5232115600	REED SENSOR
074	5313228701	REED SUPPORT
076	5213226191	FLOWMETER
077	5213215301	MOTOR BOARD
083	5513217961	MOTOR
085	7332166600	SLIDER
091	5332139200	FILTER
092	7313213261	MECHANICAL VALVE (ESAM)
093	5332149100	O-RING
094	5213214281	TERMINAL BOARD
096	5132105400	MICROSWITCH (10A/ 250V/ 125°)
097	6113211181	SPRING
098	6113211201	SPRING
099	5132110500	MICROSWITCH (250V 85°)
100	5313235751	CAM
105	5313217751	O-RING (D=6.07 T=1.78)
106	5332213000	PIN
108	5332148400	VALVE
109	6132106900	SPRING
111	5313228511	FRAME
112	5313228601	EXPANSION CHAMBER COVER
116	5313228411	LEAK DUCT
117	5332142600	HOOK
118	6013213181	FILTER (D.40X2.3 TAI-FENG)
119	9812631250	SCREW (3.5X12)
120	5332149100	O-RING
121	5332140300	PISTON
122	7313251441	INFUSER
123	5332139800	LEVER
124	6132103500	SPRING
125	5332139600	STOPPER
126	5332139500	VALVE
127	6132112200	SPRING
130	5513230831	FLOW REGULATOR
133	5313217741	O-RING (D=6.75 T=1.78)
134	5213211161	PUMP PROTECTOR
135	7313219421	SAFETY VALVE
136	5313216501	PUMP SUPPORT



138	5113211281	PUMP (ULKA 230V 48W)
139	534848	SUPPORT
142	5332177800	SILICONE HOSE (DI=4 L=200)
143	5332178100	SILICONE HOSE (DI=4 L=270)
144	5328502100	CONNECTION
145	535927	TUBE (L350)
146	5313218921	FLOWMETER TUBE GUIDE
147	5213226191	FLOWMETER
150	5513213801	TUBE WITH 2 BUSHES (L180)
151	5332177800	SILICONE HOSE (DI=4 L=200)
152	5513219841	TUBE WITH NUT AND 1 BUSH (L135)
153	6213210351	NUT
154	5232105000	SAFETY THERMOSTAT (13.5A 318°)
155	6132106000	BRACKET
156	5217100200	SENSOR (NTC L400)
157	5313216541	A T CONNECTION (PRES BLOCK)
158	IT0286	SEE TECHNICAL INFO
160	9824800009	CLIP CLAMP (8.30-8.10-7.80 )
161	6113212051	CONNECTION
162	6113210741	RING
163	6213211521	BRASS BUSH
165	5013253881	TCO WITH WIRING
166	5013253891	TCO WITH WIRING
168	6132107500	FIXING BRACKET (TCO)
170	5513227941	GENERATOR (R1200W 230V)
171	5213215661	NTC PROBE (L500)
172	6132109900	BRACKET
173	6113210021	CLIP (WIRE 1,2 AISI302)
174	5313217701	O-RING (D=3.85 T=2)
175	5332142400	BUSH
176	5332142300	BUSH
180	5513219851	TUBE WITH NUT AND 1 BUSH (L335)
181	5513213501	TUBE WITH 2 BUSHES (L150)
184	5313218341	RIGHT ANGLE CONNECTION
185	5313218351	DOUBLE CONNECTION
186	5213218471	SOLENOID VALVE
189	5513212881	TUBE WITH 2 BUSHES (L270)
191	5513226831	TUBE WITH 2 BUSHES (L500)

192	5313217611	SHAPE FOR TUBE
193	5313228671	SOLENOID VALVE A T CONNECTION
194	5513225701	SOLENOID VALVE KIT (2VA 230V)
199	5513212871	TUBE WITH 2 BUSHES (L97)
205	5313252051	SOLENOID VALVE SUPPORT
206	5513218591	TUBE WITH 2 BUSHES (L90)
208	7313223971	CARAFE COUPLING
209	5132104100	MICROSWITCH (250V 85°)
210	5313220131	COUPLING RUBBER PAD SEAL
214	5313220031	O-RING (D=9.25 T=1.78)
215	5313221011	O-RING (D6.07 T1.78)
216	5313229751	COUPLING MICRO SUPPORT (IFD)